



**Fredenstein**  
*Professional Audio*

**F676**  
**Microphone**  
**Preamplifier**  
**Operating Manual**

## **Overview:**

The Fredenstein F676 Microphone Preamplifier is a valve (tube) based preamp and with the a fully balanced signal path throughout. Its is on the input and output transformer coupled. The F6760 uses a DSP to control the operating points of the tubes, guarantying perfect working conditions all the time. The final result is a preamp with a very pleasant sonic footprint, lush smooth highs without being harsh and a very detailed mids and lows. The F676 will make a difference in the studio. The name F676 is a homage on the famous V76 microphone preamplifier designed by the German broadcast system in the early 1950's and manufactured by several German companies.

## **Installation:**

Located on he front panel, there are the LCD display, the contrast control, the rotary control button, and the TRS direct input.




Fig. 1 F676 Front Panel

On the rear panel, there are the XLR connectors for INPUT and OUTPUT, as well as the IEC MAINS POWER connector, MAINS SWITCH, and most importantly the MAINS VOLTAGE SELECTOR.

**Please select your local mains voltage first before connecting the power!**




Fig. 2 F676 Rear Panel

## Operations:

After turning on the MAINS SWITCH on the rear panel, the unit performs a self test and after successful completion you will see the following screen:



At this point the unit is in stand-by mode and the audio circuitry and the tubes are still powered-off.

To turn the F676 on, please push the rotary control. The F676 will power up and go through a tube calibration cycle. During this cycle you will see the anode currents in both halves of the push-pull Class A amplifier.



After the currents settled, the unit is fully operational and the user will be forwarded to the main menu.



The top of the main menu pages displays the peak output level meter

The Main Menu allows to modify the following parameters:

### **Amplifier Gain:**

The gain of the F676 can be adjusted in 1 dB steps in the range of 0 dB and +76 dB. To adjust the gain move the cursor with the rotary control to the gain field and then press the rotary control.

The cursor will move from the left to the right and the rotary control becomes the gain “pot”. The change is applied immediately, therefore the engineer can hear the changes right away. When satisfied with the gain, push the rotary control again and the cursor will move back to the gain field and can be moved down to select different items. This procedure applies to all parameter adjustments

### **Input Pad:**

An addition -20 dB input pad (attenuator) can be applied when dealing with very large input signals.

### **Phantom Power P48:**

Industry standard 48V Phantom Power (P48) can be turned on for microphones requiring such a power source. Please be sure the connected microphone is made for P48 before turning on. Most FET based condenser microphones use P48, while almost all tube based condenser, dynamic and ribbon microphones do not, some of them can be severely damaged if supplied with P48.

### **Input Selection:**

the choices are “Microphone”, which uses the female XLR input connector located on the back panel, or “Direct” (DI), the instrument TRS input located on the front panel. The DI accepts both balanced (TRS) or unbalanced (TS) connections. The input impedance of the DI input is much higher (470 KOhms) to avoid loading of instrument pickups. There is no P48 on the DI input.

## **Sub-Menus:**


There are two sub menus available to adjust the following parameters:

- Advanced:** Manipulation of advanced audio parameters
- Utilities:** Safe/Recall Parameters, etc.

### **Power:**

The F676 can be turned off into stand-by mode. All current settings will be automatically stored at this point and will be applied after the next turn on.

## **Advanced Audio Sub Menu:**



### **Input Impedance:**

In general the 1000 Ohms setting will work the best with most microphones. Some dynamic and ribbon microphones however require a lower termination to exhibit their optimum frequency response. In this case, please select the 200 Ohms option.

### **Low Frequency Roll-Off:**

To avoid recording unwanted low frequencies (rumble), a high-pass filter can be inserted.

The three settings are:

OFF : no high-pass filter (full frequency response)

30Hz : all frequencies above 30Hz are amplified

60Hz : all frequencies above 60Hz are amplified

### **Polarity:**

Due to placement of microphones sometimes the polarity (phase) needs to be changed.

(An example would be a bottom microphone on a snare drum) . In this case, select the reverse polarity.

### **Muting:**

The amplifier can be muted to avoid unwanted signals to come through.

### **Push-Pull versus Single-Ended Output Configuration:**


The output stage can be changed from normal push-pull to single-ended. This will change the sound characteristics. Values in between can also be achieved. Please note that the output level in single-ended mode is 6 dB lower.

### **Output Transformer DC Bias:**

Another way to influence the sonic characteristics of the F676.

A constant DC current can be chosen in the output transformer. Its characteristics are hereby altered, the frequency response becomes narrower and the amp produces more 2nd harmonic distortion.

### **Utilities Sub Menu:**



### **Store Configurations:**

The F676 allows to store 99 complete setups. Please select the storage location by turning the rotary control. If the location was previously used, it is indicated, but you can overwrite it.

### **Recall Configuration:**

You can recall the store configurations. Only previously stored configurations will be displayed and allowed to recall.

### **Factory Default:**

The F660 can be reset to factory defaults. First select Factory default and then turn the rotary control to enable, then press the control to perform the reset to the factory defaults.

### **Main Menu:**

Push main menu to get back to the root menu.

In addition the Utilities Menu displays the Output tube currents and the internal temperature. The F676 deploys an ultra low noise magnetic levitation fan inside that has a very long life span. But in case of circuit or fan failures, if the internal temperature reaches 85C (185F) the F676 will automatically shut down.

## **Specifications:**

|                     |  |
|---------------------|--|
| Frequency Response: | 20Hz – 20Khz +- 0.5dB  |
| Distortion:         | < 0.1%   |
| In put Noise:       | -128dB at +30dB gain   |
| Gain Range:         | 0 dB to +76 dB without Pad<br>+20 db to + 56db with Pad                                  |
| Threshold:          | -24dBu to + 16.5dBu  |
| Mains Voltage       | 110V to 120V in the 115V range<br>or 220V to 240V in the 230V range<br>(user selectable) |
| Power Consumption:  | < 50W  |

## **Contact Information:**

### **Fredenstein Professional Audio**

by ORION COMMUNICATION INC.

7F-1, 582, RUEI GUANG ROAD, TAIPEI, TAIWAN

TEL:+886-2-26571618, FAX:+886-2-26571610

Website: [www.fredenstein.com](http://www.fredenstein.com)

e-Mail: [info@fredenstein.com](mailto:info@fredenstein.com)