

ClearSonic MegaPac and MiniMega Instructions

1. Open all boxes and check for damage. Call us immediately if you have any damaged or missing items. Save your boxes and packing for as long as possible or at least a few weeks.
2. Stand up the main 5.5' tall base panel shield systems in zigzag formation with the base channel on bottom.



3. Peel masking off panels. (*Once masking is removed panels can not be returned. Test your MegaPac with masking first if you are not sure.*) Using gloves to handle acrylic panels will help keep them free of finger prints during assembly.

4. Install H-channels on top of 5.5' tall shields. Outside edge of H-channel should line up with outside edge of shield below. Lubricate the top of the panels with rubbing or other quick-drying alcohol solution to aid installation.



5. Note the number of panels and hinge configuration of each shield system. Be sure the number of panels matches, and that everything will fold correctly once installed. Have your assistant "feed" the folded AX panels one at a time while you place them into position atop the larger shields. Make sure the edges line up. Don't seat the AX panels completely until all are in place. Tap the top of the AX panels with rubber mallet to seat completely into H-channel on both panel systems.



6. Fold up the larger of the two panel systems and “walk” it to the front center of the drum kit or whatever you’re isolating.



7. With one person on each side, unfold the system and wrap it around the kit.



8. Use your fingers to lift the panels at the bottom cable cut-outs to pull or push system into final position. End panels should be parallel and symmetrical on either side of the kit, about 7 feet apart for most applications.



9. Wrap the smaller panel system around the back so it meets with front panels on both sides.



10. Next, use extra base channel included with your MegaPac to connect the front panels with the rear panels on the side opposite the door. Line up the end panels of both shields, and attach the base channel to the top of the AX extenders.



11. The extra 'H' channel provided with your MegaPac will help keep the lid from obstructing the door panel when entering and exiting. Place this on top of the AX panel next to your door.



12. Adjust both Lid support bars to the width of the front panels. Rest one support bar on top with the J-hooks at least 4-inches from the edge of the end panels. Place the other bar about a foot in front of the first. Do not extend the bar beyond the red limit mark.



13. Lay the rectangular 2' wide STC5 on top (about six inches from the center of the front panels) with at least a one inch over-hang in front. The Lid sections will be resting on the support bars in back. Place the 1' wide STC512 right next to it with same over-hang. Complete the lid with the STS trapezoid sections. You may have to make adjustments to the panels and/or lid in order to achieve maximum coverage.

14. If not pre-attached, place Velcro on all four corners of the S2 and S1 baffles about 1-inch from the edge. Peel off the paper to expose the adhesive

15. Place the S2 and S1 baffles in position on the shields. When attaching SORBER baffles to your door panel, raise the bottom S2 approximately $\frac{1}{2}$ inch off the ground so it does not drag. It works best to have an assistant apply pressure from the opposite side while pressing on the baffle corners to make sure the Velcro sticks securely. (See SORBER diagram on following page for configuration)

16. Clip fan to the back of the STC or on one of the support bars to aid in air exchange.

17. Enjoy Your MegaPac!

SORBER Baffle Placement for MegaPac

Front A5-7

S1						S1
S2						S2
S2						

S2 Baffle Placement for MiniMega

Front A5-6

S2					S2
S2					S2
S2	S2	S2	S2	S2	S2

Rear A5-5

S1	S1	S1	S1	S1
S1	S1	S1	S1	S1
S2	S2	S2	S2	S2
S2	S2	S2	S2	S2

Rear A5-5

S2	S2	S2	S2	S2
S2	S2	S2	S2	S2
S2	S2	S2	S2	S2



ClearSonic MegaPac



ClearSonic Mini-MegaPac

Thank you for using ClearSonic products. Please contact us should you have any questions or concerns about MegaPac assembly or operation.

800-888-6360 * info@clearsonic.com